



# Cubic Designs Inc.

16770 WEST VICTOR ROAD  
NEW BERLIN, WI 53151  
262-789-1966 800-826-7061 FAX: 262-789-1970

## FLOOR PLATE LAYOUT

### FLOOR PLATE COVER

LAY OUT ALL FLOOR PLATE SHEETS PER FLOOR PLATE LAYOUT DRAWING AND ADJUST GAPS AS NEEDED. POSITION MOST OF GAP ALONG WALL OR KICK- PLATE. STAGGER JOINTS PER LAYOUT SHOWN AT RIGHT. BUTT SHEETS OVER DECK RIBS PER SECTION VIEW SHOWN AT LOWER RIGHT.

ONCE ALL SHEETS ARE LAID OUT AND GAPS ADJUSTED, DRILL  $3/16"$  HOLES THROUGH PLATE AND DECK RIBS PER PATTERN SHOWN AT RIGHT. RIVET EACH FULL SHEET USING A MINIMUM OF (12) RIVETS PER SHEET. INCREASE NUMBER OF RIVETS WHERE NEEDED TO HOLD SHEET FLAT.

DETAIL

42A

